



Biamp USB 200

Quick Start Guide


What Is In The Box




Mounting Options



Use the screw and plug to mount the USB 200 to the wall



Use zip ties to attach the USB 200 to the wall-mount brackets at the back of the monitor



LED Behavior

Status	State
PC1 selected - PC1 LED	●
PC2 selected - PC2 LED	●

Get Started

- 1 Use the Switch to select the Manual or Priority Mode.
- 2 When using Manual Mode, connect an external control system switch connector.
- 3 Connect USB cables (not included) to the device and Host PC's.
- 4 If auxiliary power supply is required, connect mains power via the power supply unit.
- 5 See the application diagram for the recommended setup.

Featuring

- Supports both USB 2.0 and USB 3.0.
- Power switch delay cuts power for 2 seconds when switching between computers, to secure stable switching of the device.
- Built-in USB extender extends USB 2.0 cable lengths to up to 17 feet (5m) and USB 3.0 cable lengths up to 10 feet (3m) on each side of the switch.

Application Diagram

